

To determine the size remnant you need, you will need to know the following:

1. Measure the space between walls or wall to edge of cabinet.
2. You will then need to add the appropriate overhangs to the exposed sides of the cabinet.
(If you have inset cabinet doors, standard $3/4$ " and if you have overlay doors standard is $1\ 1/2$ ")
3. Next, you will need to decide on back splash, choose you back splash height and the number of walls you wish to cover.
4. Now, you will want to add these dimensions together into one rectangle to determine the minimum size remnant you will need. When you search for remnants, you will notice each remnant has dimensions listed.
5. For the drawing below, we will need a remnant that is 53.5" X 27.5"

